

TABLA PARA SELECCIÓN DE BOQUILLA, CAÑÓN NELSON P85 Y P65

ALCANCES Y CAUDALES SEGÚN PRESIÓN

P85

DIÁMETRO BOQUILLA	11/32" 0,343" 8,73 mm	3/8" 0,375" 9,52 mm	13/32" 0,406" 10,31 mm	7/16" 0,437" 11,11 mm	15/32" 0,468" 11,90 mm					
PRESIÓN Bar	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.
3.0	5.1	21	6.1	22	7.2	23	8.1	24	9.3	25
4.0	5.9	23	7.0	24	8.3	25	9.5	26	10.8	27
5.0	6.6	25	7.9	26	9.3	27	10.6	28	12.1	29
6.0	7.3	26	8.6	27	10.1	28	11.7	29	13.4	30

DIÁMETRO BOQUILLA	1/2" 0,500" 12,70 mm	17/32" 0,531" 13,49 mm	9/16" 0,562" 14,28 mm	5/8" 0,625" 15,87 mm	11/16" 0,687" 17,46 mm					
PRESIÓN Bar	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.
3.0	10.6	26	11.9	26	13.3	27	16.1	28	19.5	30
4.0	12.3	28	13.8	29	15.4	29	18.7	31	22.5	32
5.0	13.8	30	15.5	30	17.3	31	20.9	33	25.2	34
6.0	15.1	31	17.0	32	19.0	33	22.8	34		



P65

DIÁMETRO BOQUILLA	7/32" 0,218" 5,55 mm	1/4" 0,250" 6,35 mm	9/32" 0,281" 7,14 mm	19/64" 0,296" 7,54 mm	5/16" 0,312" 7,93 mm	21/64" 0,328" 8,33 mm	11/32" 0,343" 8,73 mm	23/64" 0,359" 9,12 mm	3/8" 0,375" 9,52 mm									
PRESIÓN Bar	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.	M ³ /H	Radio mts.		
2.0	1.70	15	2.21	16	2.77	17	3.07	17	3.43	18	3.69	18	4.03	18	4.39	18	4.70	19
2.5	1.90	16	2.48	17	3.10	18	3.40	18	3.80	19	4.12	19	4.49	19	4.86	19	5.23	20
3.0	2.08	17	2.71	18	3.38	19	3.73	19	4.18	20	4.51	20	4.92	20	5.34	21	5.74	21
3.5	2.24	18	2.93	19	3.64	20	4.05	20	4.51	21	4.87	21	5.33	21	5.78	22	6.19	22
4.0	2.41	19	3.15	19	3.93	20	4.31	21	4.82	22	5.20	22	5.67	22	6.14	23	6.56	23
4.5	2.57	19	3.35	20	4.16	21	4.57	22	5.12	22	5.53	23	6.03	23	6.49	24	6.94	24
5.0	2.70	20	3.53	21	4.38	22	4.84	22	5.39	23	5.84	23	6.38	24	6.85	24	7.37	25
5.5	2.83	21	3.70	22	4.60	23	5.10	23	5.65	24	6.12	24	6.69	25	7.19	25	7.73	25



Rudolf Diesel 1, Pol. Molino del Pilar - 50015 Zaragoza

Teléfono: **976 22 55 17*** - Fax: 976 22 72 06

E-mail: traxco@traxco.es